
Meridian 1

Digital Trunk Interface/Computer-to-PBX Interface

Maintenance

Document Number: 553-2811-500

Document Release: Standard 4.0

Date: December 1994

© 1984, 1994

All rights reserved

Printed in the United States of America

Information is subject to change without notice. Northern Telecom reserves the right to make changes in design or components as progress in engineering and manufacturing may warrant. This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC rules.

SL-1 and Meridian 1 are trademarks of Northern Telecom.

Revision history

September 16, 1991

Standard, release 1.0. Reissued for compliance with Northern Telecom standard 164.0.

December 1, 1991

Standard, release 2.0. This document is reissued to include technical content updates. Due to the extent of changes revision bars are omitted.

August 1, 1993

Standard, release 3.0. This document is reissued for updates and changes resulting from X11 release 19. All updates are noted with revision bars in the margins.

December 1994

Standard, release 4.0. Reissued to include editorial changes and indexing. Due to the extent of the changes, revision bars are not used.

Contents

Introduction	1
Document overview	1
Other documentation	2
Affected programs	2
TN to channel number conversion	3
DTI fault clearing	5
DTI status check	5
Red alarm (local alarm)	7
When a red alarm occurs	8
Yellow alarm (remote alarm)	9
When a yellow alarm occurs	9
DTI problems	10
Maintenance procedures	11
DTI commands (LD 60)	11
Self-test	16
Automatic loop test	17
Link diagnostic and remote loopback tests	17
DTI system messages	20
DTI error detection	30
Bit error rates	30
Frame slip	32
Frame alignment	35

Using the Error Counter	37
Error Counter switch functions	38
Error Counter display functions	38
Replacing the DTI card	39
DTI cabling	42
Clock Controller maintenance	45
Clock operation	45
Tracking mode	45
Free run (non-tracking) mode	45
Reference clock errors	46
Automatic clock recovery	47
Automatic clock switching	47
Clock Controller commands (LD 60)	48
Replacing the Clock Controller	50
Clock Controller switch settings	52
Clock Controller cabling	54

List of figures

Figure 1	
DTI alarm timers	8
Figure 2	
DTI remote loopback test and DTI link diagnostic test	19
Figure 3	
Bipolar violations	30
Figure 4	
BIPV and BIPC thresholds	31
Figure 5	
DTA messages	33
Figure 6	
DTA thresholds	34
Figure 7	
Frame alignment thresholds	35
Figure 8	
Loss of frame alignment	36
Figure 9	
Transmission equalization switch settings	41
Figure 10	
DTI cabling with Echo Canceller	42
Figure 11	
DTI cabling without Echo Canceller	43
Figure 12	
Clock Controller primary and secondary tracking	46

Figure 13	
Clock Controller cabling: ST and N/NT/RT half-group	54
Figure 14	
Clock Controller cabling: N/NT single-group	55
Figure 15	
Clock Controller cabling: XN/XT multi-group	55

List of tables

Table 1	
DTI channel numbers and equivalent terminal numbers	3
Table 2	
DTI problem solving	10
Table 3	
Card and channel commands	11
Table 4	
Test commands	14
Table 5	
Alarm and counter commands	15
Table 6	
PRI/DTI alarm messages	20
Table 7	
DTI/PRI error messages	22
Table 8	
BIPV thresholds	32
Table 9	
Error Counter switch functions	38
Table 10	
Error Counter display functions	38
Table 11	
QPC720 transmission equalization SW2 switch settings for PRI/DTI	39

Table 12	
QPC472 transmission equalization SW2 switch settings for DTI	40
Table 13	
Transmission equalization switch settings for QPC720	
PRI/DTI mode	40
Table 14	
Clock Controller commands (LD 60)	48
Table 15	
DTCxxx messages	49
Table 16	
Clock Controller switch settings	52
Table 17	
Clock Controller switch settings for QPC471 vintage H	53